




# QUICK START GUIDE

Parking system based on long range proximity readers



## Configuration:

- Terminal ID0, [04]: Wiegand 26...66 bit reader, only card
- Terminal ID1, [04]: Wiegand 26...66 bit reader, only card
- REL1 Output, [97]: Entry door lock
- REL2 Output, [98]: Exit door lock

## Technical support is available in weekdays:

- from 8:00 am to 4:00 pm at PSTN number +48 55 267 01 26
- from 4:00 pm to 8:00 pm at GSM number +48 664 294 087