




# QUICK START GUIDE

Connection scheme of PR402DR controller and XM-8 elevator module



Typical connection scheme of PR402DR controller and XM-8 elevator module with automatic relays switching to OFF mode option.

## Technical support is available in weekdays:

- from 8:00 am to 4:00 pm at PSTN number +48 55 267 01 26
- from 4:00 pm to 8:00 pm at GSM number +48 664 294 087